









477202




987202




477202




987202



477202




987202







1




2




3




4



5




6




7


477202







987202




8








13




14



15




16




ramonsoler.




17




18




19




20




21




22



23




24







25



26



Mantenimiento . Maintenance . Entretien . Pflege



Es importante limpiar periódicamente las boquillas de silicona, pasar los dedos sobre las boquillas haciendo que se desprenda la cal.

Is important to clean the silicone outlets periodically though the finger in order to avoid limescale accumulation.

Il est important de nettoyer périodiquement les picots en silicone, de passer les doigts sur les picots, ce qui fait décoller le calcaire.

Die Silikonknoppen regelmäßig zu reinigen. Wischen Sie mit den Fingern leicht über die Düsen, um ein Verstopfen durch Kalkablagerungen zu vermeiden und optimalen Wasserstrahl zu gewährleisten.



